

# Fuel Pump Mount Kit

To suit VL Commodore and Calais  
Sedan and Wagon

by F2K Parts Australia

[www.f2thak.com](http://www.f2thak.com)

## INSTALLATION:

1. Remove bracket from vehicle.
2. Disassemble bracket, taking note of how it goes together. Use a 13mm spanner for the nuts and a 19mm spanner to remove the old rubber mounts.
3. Install new rubber mounts, ensuring the long thread side with spacer nut are on the bottom as shown below. Tighten into place with 13mm spanner. There is no replacement mount for the top one.
4. Reassemble using new nuts and bolts, then refit to vehicle using the three new bolts.

**Install new mounts  
with nuts on  
the bottom**

