

Calais “Popup Lights” Control Loom

Suits all VL Commodores, including SL / Executive / Berlina

Designed and manufactured by F2K Parts Australia

www.f2thak.com

INSTALLATION:

NOTE: Do not install the fuse until last step

1. Connect the **Red** wire ring terminal to the battery positive terminal
2. Connect the **Black** wire ring terminal to either:
 - the 10mm ground bolt near the battery (Looks neater)
 - OR, the battery negative terminal
3. Splice the **Brown** wire into the headlight low beam wire, which is shown below. The plug is on the main body loom and is the end plug on the drivers side in the engine bay. We highly recommend that this join is soldered, but at the very least use some electrical tape to insulate the join.
4. Mount the loom near the battery using the relay bracket and self-tapping screw; or in a location of your choice.
5. Plug the Popup Light Motor loom into the white plug on the Control loom
6. Insert the fuse and you're done!

